

# **OPERATORS MANUAL**

**model**

# **PRO GOLF DEMOUNT**

**PGDM400**

**PGDM600**

**PGDM800**

**PGDM1000**



**CLEVELAND ALLIANCES LTD**  
**INDUSTRY AGRICULTURE AMENITY**

**For AMC180 & 400 Rate controllers see other manuals on our website**

**For WGF Shrouded booms see other manuals on our website**

**Disclaimer:**

**Cleveland Alliances Ltd accept no liability for damage caused to the machine or the environment or persons through operation or misuse of the machine. The operator must be competent, trained, and have the appropriate certification.**

**DO NOT USE THIS MACHINE UNLESS YOU HAVE BEEN TRAINED TO DO SO.**

**For technical support and spare parts assistance call 01361883418**

**Email us on [info@clevelandalliances.com](mailto:info@clevelandalliances.com)**

**Cleveland Alliances Ltd**

**Station Road, Duns, Berwickshire, TD113HS**

Thank you for purchasing your Cleveland Gambetti Sprayer. Here are the do's and don't of operation and how to keep spraying without any hassles.

**Disclaimer:**

Cleveland Alliances Ltd accept no liability for damage caused to the machine or the environment or persons through operation or misuse of the machine. The operator must be competent, trained, and have the appropriate certification.

**DO NOT USE THIS MACHINE UNLESS YOU HAVE BEEN TRAINED TO DO SO.**

Spraying is a delicate operation and involves the risk of contamination of people, animals and the environment. For this reason the functionality of all machine components must be carefully ensured. - The operator is always the most exposed person to the used chemical products and he/she must always adopt all the necessary measures for his/ her personal safety at work. Refer to the danger indications on the labels of the products used. - Always work in the correct weather conditions and follow the weather forecasts for the entire period of application. - Dose the product to be poured into the tank correctly. - Make sure that the chemical substances used are compatible with the construction materials of the machine. - Never leave chemical substances on the tank for more than a few hours. - Carefully follow the regulations concerning the possession and use of plant protection products and make sure that people and animals cannot access them. - After each use carefully wash the containers of the mix and the dosing tools that have been used. - Do not use the machine without hand washing tank or if it is not full. - The machine should be cleaned in the same place where it is filled, i.e. an area where the water can be collected in a disposal manhole. - Do not discharge the mixing residues to the watercourses, sewers and public areas.



# FITTING TO THE TRUCK

## **NEVER WORK ON THE MACHINE WHILST THE ENGINE IS RUNNING**

- 1.** Connect the machine to the lower links onto the truck body using the jacking handles to adjust the height. DO NOT PUT FINGERS INTO THE PIN HOLES WHEN ALIGNING THE SPRAYER TO THE TRUCK. Connect the two rear pins and then connect the centre front pin to the tipping ram. Make sure all lynch pins / R pins are in place
- 2.** When the machine is connected to the truck check the area is clear and lift the Sprayer using the tipping ram. Then connect the hydraulic pump hoses to the hydraulic service on the truck. The engine should NOT be running when doing this.
- 3.** Connect the electrical cables to the control boxes.


**NEVER LIFT THE SPRAYER WITH THE TIPPING HYDRAULIC RAM WHEN THERE IS LIQUID INSIDE THE TANK!**

## Operation:

Do not just bash on, hoping you're going to get it right!!! You're applying thousands of pounds worth of product... lets do a good job shall we.....

1. Connect to the TRUCK following the previous page instructions. Make sure the sprayer chassis is sitting level and the nozzles are 50cm from the ground when the machine is at the working position on the vehicle
2. Put water inside the tank. ONLY ADD PRODUCT when there is at least 150lt of water in the tank. The pump MUST BE RUNNING via the hydraulic PTO when adding CHEMICAL. If you just add chemical without the pump running you risk choking your suction filter which will be a real pain in the backside for you.
4. Add the rest of the water to the required level.

## Controls:



### Pressure Relief valve

To set the relief valve, put the PTO speed to 540 rpm and start spraying water. Set the pressure to 5 bar using the YELLOW adjuster. Then unscrew the green knob (anti clockwise) until the pressure drops to 4.8 bar

## Boom Section Valves

The sections are controlled from the cab switch box

**Pressure Balancing** - To set the pressure balancing valves, follow this procedure:

1. Set the total boom spraying @ 3bar pressure
2. Turn off section 1, if the pressure increases above 3 bar, turn the balancing valve anti clockwise until the pressure is at 3 bar. If the pressure decreases below 3 bar, turn the balancing valve clockwise until the pressure is at 3 bar. Switch the section back on so the whole boom is spraying. Repeat the procedure for sections 2,3,4,5



## Operation:

The switch box comes with a 12v 'D' plug for power. Modern tractors should come with a female D plug installed. If it has not, get your dealer to install one. Push in cigarette lighter type sockets are not good enough for professional 12v connections.

**Electric controls supplied as either 3 section or 5 section:**


Boom section switches






## Tank Suction & Tank Drain

Underneath the main tank , at the rear of the machine is a valve which has 2 positions.



### DRAIN POSITION


The valve must be pointing **RIGHT** to allow the tank contents to drain out



### MAIN TANK SUCTION OR CLEAN WATER SUCTION

Valve Arrow pointing **RIGHT**= Clean Water Suction

Valve Arrow pointing **LEFT** = Main Tank Suction



### SUCTION FILTER LOCATED UNDER THE PUMP

To clean the suction filter (WEEKLY) you must remove the yellow plunger first. Once it is removed, you should unscrew the large filter nut and remove the filter element to clean. Be careful not to lose the large filter O ring in the housing. Once cleaned, put back together and make sure the filter is fully assembled before replacing the yellow plunger



## Chemical Mixer Hopper



CLEVELAND ALLIANCES LTD  
INDUSTRY AGRICULTURE AMENITY

To use the induction hopper, there must be water in the main tank and the pump needs to be running at a minimum PTO speed of 400rpm.



Arrow on the valve handle pointing towards the centre of the hopper (left) means the hopper is on and ready to use

Arrow on the valve handle pointing towards the boom (right) means the hopper is off and you are ready to spray.

**THE MACHINE WILL NOT SPRAY IF THE HOPPER IS ON**





## Boom Operation



CLEVELAND ALLIANCES LTD  
INDUSTRY AGRICULTURE AMENITY

### 6m boom

The 6m boom has 4 nozzles per boom section at 50cm spacing. The boom is equipped with spring adjusted break-back devices in case of collision. The tension on the springs can be adjusted by the 30mm nut on top of the boom hinge. Do not make too tight. Doing so can cause too much rigidity and cause the boom to bend in there is collision. Usually 20 to 25mm of thread above the adjustment nut is adequate.

To open the boom:

- Pull the right hand boom arm towards you and open it towards the right hand side of the machine. Be sure to locate the boom in the fully open position
- Once the right hand boom arm is secured, pull the left hand boom arm towards you and open it towards the left hand side of the machine. Be sure to locate the boom in the fully open position

On a weekly basis, APPLY GREASE to the folding mechanism when the boom arm is half way between being full open and fully closed. **WARNING: DO NOT MOVE THE BOOM ARM WHEN YOU ARE GREASING THE BOOM HINGE. YOU MAY TRAP YOUR FINGERS IN THE MECHANISM. TAKE NOTE**



When **closing**, close **LEFT** hand boom arm first

When **opening**, open **RIGHT** hand boom arm first

## Boom Operation

6m Hydraulic/Electric Boom


8m Hydraulic / Electric Boom

The 6m boom has 4 nozzles per boom section at 50cm spacing. The 8m boom has 4 nozzles in the centre, 3 nozzles on the first section and 3 nozzles on the second section. The boom is equipped with spring adjusted break-back devices in case of collision. The tension on the springs can be adjusted by the 30mm nut on top of the boom hinge. Do not make too tight. Doing so can cause too much rigidity and cause the boom to bend in there is collision. Usually 20 to 25mm of thread above the adjustment nut is adequate.

To open the boom:

- You will have 2 switches mounted on a box which has a 12v feed near the drivers position
- You can open either boom at any time or both booms together. There is a fuse for each switch underneath the switch on the external area of the switch box

On a weekly basis, APPLY GREASE to the folding mechanism when the boom arm is half way between being full open and fully closed. **WARNING: DO NOT MOVE THE BOOM ARM WHEN YOU ARE GREASING THE BOOM HINGE. YOU MAY TRAP YOUR FINGERS IN THE MECHANISM. TAKE NOTE**



Golf 6m







Golf 8m



CLEVELAND ALLIANCES LTD  
INDUSTRY AGRICULTURE AMENITY



## Nozzle Application Chart

COD. 110° CODE 110° CÓD. 110°				l/ha (spazio tra gli ugelli: 50 cm) l/ha (nozzle spacing: 50 cm) l/ha (espacio entre las boquillas: 50 cm)												COD. 80° CODE 80° CÓD. 80°
	bar	drop 110°	l/min	4 km/h	6 km/h	8 km/h	10 km/h	12 km/h	14 km/h	16 km/h	18 km/h	20 km/h	25 km/h	drop 80°		
SF11001	1.5	F	0.28	85	57	42	34	28	24	21	19	17	14	F	SF08001	
	3	VF	0.40	120	80	60	48	40	34	30	27	24	19	VF		
	5	VF	0.52	155	103	77	62	52	44	39	34	31	25	VF		
	7	VF	0.61	183	122	92	73	61	52	46	41	37	29	VF		
SF110015	1.5	F	0.42	127	85	64	51	42	36	32	28	25	20	F	SF080015	
	3	VF	0.60	180	120	90	72	60	51	45	40	36	29	VF		
	5	VF	0.77	232	155	116	93	77	66	58	52	46	37	VF		
	7	VF	0.92	275	183	137	110	92	79	69	61	55	44	VF		
SF11002	1.5	F	0.57	170	113	85	68	57	48	42	38	34	27	F	SF08002	
	3	F	0.80	240	160	120	96	80	69	60	53	48	38	F		
	5	VF	1.03	310	207	155	124	103	89	77	69	62	50	VF		
	7	VF	1.22	367	244	183	147	122	105	92	81	73	59	VF		
SF110025	1.5	F	0.71	212	141	106	85	71	61	53	47	42	34	---	NA	
	3	F	1.00	300	200	150	120	100	86	75	67	60	48			
	5	VF	1.29	387	258	194	155	129	111	97	86	77	62			
	7	VF	1.53	458	306	229	183	153	131	115	102	92	73			
SF11003	1.5	M	0.85	255	170	127	102	85	73	64	57	51	41	M	SF08003	
	3	F	1.20	360	240	180	144	120	103	90	80	72	58	F		
	5	F	1.55	465	310	232	186	155	133	116	103	93	74	F		
	7	VF	1.83	550	367	275	220	183	157	137	122	110	88	VF		
SF11004	1.5	M	1.13	339	226	170	136	113	97	85	75	68	54	M	SF08004	
	3	F	1.60	480	320	240	192	160	137	120	107	96	77	F		
	5	F	2.07	620	413	310	248	207	177	155	138	124	99	F		
	7	F	2.44	733	489	367	293	244	209	183	163	147	117	F		
SF11005	1.5	C	1.41	424	283	212	170	141	121	106	94	85	68	C	SF08005	
	3	M	2.00	600	400	300	240	200	171	150	133	120	96	M		
	5	M	2.58	775	516	387	310	258	221	194	172	155	124	M		
	7	M	3.06	917	611	458	367	306	262	229	204	183	147	M		
SF11006	1.5	C	1.70	509	339	255	204	170	145	127	113	102	81	C	SF08006	
	3	C	2.40	720	480	360	288	240	206	180	160	144	115	C		
	5	C	3.10	930	620	465	372	310	266	232	207	186	149	C		
	7	C	3.67	1.100	733	550	440	367	314	275	244	220	176	C		
SF11008	1.5	C	2.26	679	453	339	272	226	194	170	151	136	109	C	SF08008	
	3	C	3.20	960	640	480	384	320	274	240	213	192	154	C		
	5	C	4.13	1.239	826	620	496	413	354	310	275	248	198	C		
	7	C	4.89	1.466	978	733	587	489	419	367	326	293	235	C		
SF11010	1.5	C	2.83	849	566	424	339	283	242	212	189	170	136	C	SF08010	
	3	C	4.00	1.200	800	600	480	400	343	300	267	240	192	C		
	5	C	5.16	1.549	1.033	775	620	516	443	387	344	310	248	C		
	7	C	6.11	1.833	1.222	917	733	611	524	458	407	367	293	C		
SF11015	1.5	VC	4.24	1.273	849	636	509	424	364	318	283	255	204	---	NA	
	3	VC	6.00	1.800	1.200	900	720	600	514	450	400	360	288			
	5	VC	7.75	2.324	1.549	1.162	930	775	664	581	516	465	372			
	7	VC	9.17	2.750	1.833	1.375	1.100	917	786	687	611	550	440			

